



**T: 01952 677785**  
**M: 07713 678700**

## Installation Instructions

Thank you for purchasing this VentureShield™ Protection Film Kit.

Please read the simple instructions below fully prior to attempting installation and then you should be able to install this kit trouble-free.

For application purposes you will have received a mist spray bottle containing fitting solution and a rubber squeegee.

### Step 1.

Clean the areas of paintwork thoroughly by using a degreaser or methylated spirits to remove any polish from the painted surface. *(Always test a small area of paintwork first, especially if applying to fresh paintwork.)*

### Step 2.

Using the enclosed diagram identify and separate the parts from the pre cut sheet by cutting out, so as not to contaminate any parts awaiting fitment.

### Step 3.

Spray the fitting solution onto the area of paintwork to be fitted and peel back the part from the sheet whilst continuously spraying the solution onto the adhesive side of the film.

*Avoid touching the adhesive when dry, as this will leave a fingerprint in the film. (Tip: Spray some solution onto your fore finger and thumb when peeling off the backing paper).*

### Step 4.

Lay the film onto the panel and slide into position, lining up any pre cut areas first.

### Step 5.

It is recommended that you start with relatively flat panel first to learn the characteristics of the film before attempting the curved surfaces.

Once you are happy with the positioning of the panel, spray some more solution on to the face of the film and starting from the center of the film and working out towards an edge squeegee using short strokes and suitable pressure to remove any fluid and air bubbles, this will secure the film into place.

When dealing with curved panels tension will need to be applied for the film to take to the contours of the panel. Pull gently in the direction required and you will find that the film will naturally take to the curvature of the panel.

If you find that the film is incorrectly positioned, peel off using a quick jerking motion and restart the application.

When using the squeegee on the film use adequate solution to allow the squeegee to glide on the surface of the film.

If any puckers appear in the film work out towards an edge using either the squeegee or your thumb to gently spread the film. Avoid going across the pucker as this may create a wrinkle in the film and always squeegee out towards the closest edge of the film to remove completely.

### Step 6.

Continue working the film until all areas are secured and then dry off any excess fluid with a paper towel. Should you find an edge that won't adhere hold down for approx. 20-30 seconds using your thumb and the heat transfer from your body will help activate the adhesive in this area.

### Step 7.

Finally, use a hair dryer or similar to warm up film to ensure adhesion especially around edges etc.

---

## Aftercare Instructions

Once the film has been applied you may treat the surface as you would a normal painted surface.

However, please take care when washing or polishing especially around the edges of the film as you may cause lifting.

## Guarantee

VentureShield is guaranteed for six years against yellowing, cracking, bubbling or peeling providing fitment carried out to manufacturers' specifications.

This kit has been tested for fitment to the specified vehicle and every care has been taken to ensure ease of application, however should you experience any difficulty please contact your local distributor for assistance.

As we have no control over the use of your vehicle we cannot guarantee against penetration of the film although we can guarantee that this product will greatly minimize the risk of damage caused by stone-chips, insect damage and minor abrasions etc.